Technische Information für Montage und Betrieb

Technische Änderungen vorbehalten

24002.458 16-01-2014

Solar-Handfüllpumpe Art.-Nr. 45100.2	**DE**
Solar manual filling pump Art.-No. 45100.2 Technical information for installation and operation	**GB**

Meibes System-Technik

Ringstraße 18 - D - 04827 Gerichshain - Tel. + 49(0) 3 42 92 7 13-0 - Fax 7 13-50

www.meibes.de - e-mail: info@meibes.de

meibes

Effiziente Energietechnik

Montage


3/4" IG
Achtung!
Kappe für Schlauchanschluss
nur handfest anziehen.
213 mm

Montage



Handfüllpumpe am KFE-Hahn (an Sicherheitsgruppe) anschließen. Schlauchenden in den Behälter mit dem Medium für die Anlage hängen.

Die Handfüllpumpe ist selbstansaugend und braucht nicht vorab befüllt werden.

Medium solange im Kreislauf fördern, bis ausreichende Spülung bzw. Entlüftung erfolgt ist.

Achtung!
Keine trinkbaren, ätzenden, brennbaren oder explosiven Stoffe verwenden.

Installation



Installation



Connect the manual filling pump to the fill and drain ball valve (on the safety group). Hang the ends of the hoses in the container with the medium for the system.
The manual filling pump is self- priming and does not need to be filled in advance.
Keep the medium moving through the circuit until sufficiently flushed/bled.

Warning!
Do not use for drinkable, corrosive, flammable or explosive substances!